



Zephyr Block™

INSTALLATION INSTRUCTIONS

Requirements for secure adhesion:

Tile surface must be clean and dry to insure adhesion of ridge vent's butyl adhesive. Install when ambient temperatures are between 41°F and 104°F. After ridge, nail boards and field tiles are installed, install Zephyr Block as follows:

1. Place a trim piece of tile at both ends of the ridge or hip, strike a line on the field tiles on both sides of the trim tiles. This will be a guide to insure the Zephyr Block™ does not over extend the width of the trim tiles.
2. Roll out and align Zephyr Block™ starting at one end and center on ridge or hip board, then fasten through the centerline on the Zephyr Block™ onto the top of the ridge or hip board, butyl strip down. Allow for 6 inch overhang at gable. Fold onto gable and fasten. When continuing with a new roll, the connecting parts must overlap at least 2 inches. **Note:** keep roll out of direct heat or sunlight prior to application for easy removal of the release film from the butyl adhesive strips.
3. Remove the plastic release film from the butyl and form to the top surface of the last course of field tile at the pre-marked chalk line. Carefully press the edges where the butyl is applied to the tiles. It is important to start at each highest point on a high profile roof tile, then stretch and work down into the valleys to insure complete adhesion the entire length of the Zephyr Block™ on both sides of each hip and ridge.
4. Attach trim tiles on ridge and hips.